



DURABILITY • POWER • PERFORMANCE

EVEN HEAT™ HEAT DISTRIBUTION PLATE

Includes: 1X Heat Plate



CARE AND SAFETY INSTRUCTIONS

PART NUMBER: 85-1988 (G522-0072-02)

EXACT FIT FOR COLEMAN® EVEN HEAT™ MODELS:

85-3026-0 (G52205/09), 85-3027-8 (G52206/10), 85-3028-6 (G52207/11),
85-3029-4 (G52208/12), 85-3046-2 (G35301/03), 85-3047-0 (G35302/04),
85-3066 (G35305/08), 85-3067 (G35306/09), 85-3068-0 (G52215/20/27),
85-3069-8 (G52216/21/28), 85-3074-4 (G52217), 85-3075-2 (G52218),
85-3092-0 (G52222), 85-3093-8 (G52223), 85-3076-0 (G53101/03),
85-3077-8 (G53102/04), 85-3077-8(G53102/04), 85-3114-0 (G52229), AND 85-3115-8 (G52230)

READ AND SAVE MANUAL FOR FUTURE REFERENCE.

The Even Heat™ Heat Distribution Plate is designed and intended for use with Coleman® Even Heat™ Barbecues only. This product will replace the original heat distribution plate sold with your Coleman® Even Heat™ Barbecue.

CARE AND SAFETY



ATTENTION

- **Move grill to an open outdoor area prior to removing old heat distribution plates and installing your NEW heat distribution plates**
- **Ensure grill is cool before proceeding and close the control knob(s) and gas supply.**
- **Lift BBQ Lid to expose your BBQ's cooking surface.**
- **Remove your cooking grates.**
- **Remove your damaged heat distribution plate and replace with your NEW heat distribution plate.**
- **Ensure that your heat plates are seated directly over your burner and under your cooking grates.**

CARE AND CLEANING REGIME

Your new Even Heat™ Heat Distribution Plates will protect burners from direct drippings of grease, fats and salty marinades, distribute heat evenly across the cooking surface and incinerate grease drippings creating the authentic barbecue flavours we love.

When allowed to accumulate, the build-up of grease may cause a number of safety issues, including; flare-ups and grease fires. Failure to follow the steps outlined below may lead to rapid deterioration of this part, moisture damage or rust-through.

1. Remove and clean heat distribution plates every other time you barbecue.
2. Use a grill brush to remove buildup. We recommend doing this over a large garbage receptacle.
3. Clean away all remaining debris with mild soap and warm water.
4. Dry thoroughly.
5. Re-install.



Join the conversation



facebook.com/colemangrills



twitter.com/colemangrills

*Distributed by: Winners Products Engineering Ltd.
Coleman® , and  are registered trademarks of the Coleman Company, Inc used under license. ©2016 The Coleman Company, Inc.*

www.colemanbbqs.com